


# Visual Instruction Guide for the Mini DV 1280 Video Camera



## Visual Instruction Guide for the Mini DV 1280 Video Camera

- 1) Turn the camera on by hold “on/off” for 3 seconds
- 2) Cycle through the three main modes by pressing ‘Mode’. You can identify the current mode by looking at the blue and red LEDs. For example, a solid Red light indicates “Standby” mode.

Mode	Lights	Notes
Standby	Solid Red	Press “on/off” to record video
Recording Video	Flashing Red	Press “on/off” to stop
Camera	Solid Blue	Press “on/off” to take photo. Blue LED will flash once.
Motion Detect	Solid Red, Solid Blue	Any motion will start video recording
Motion Detected – Video Recording	Flashing Red, Solid Blue	Press “on/off” to manually stop recording

- 3) The “on/off” button takes a different action depending on the mode you are in. For example, in Standby mode (indicated by a solid red LED), the “on/off” button will start recording (indicated by flashing red LED). See the table and/or infographic above for details.

How to Video: <https://www.youtube.com/watch?v=X1sYfPHe0fc>